Table 1. Electrical and Environmental Specifications (At V_{supply} = 3.8 Vdc to 30 Vdc, T_A = -40 °C to 150 °C [-40 °F to 302 °F] except where otherwise specified.)

Characteristic	Condition	Min.	Тур.	Max.	Unit
Supply voltage	no load	3.8	_	30	Vdc
Supply current: operated released	24 °C ±2 °C, 16 Vdc ±0.5 % V _{supply} 24 °C ±2 °C, 16 Vdc ±0.5 % V _{supply}		6 6	11 10	mA
Output leakage current (released)	_	_	_	10.0	μΑ
Output voltage (operated)	sinking, 20 mA max.	_	0.25	0.40	V
Outptut switching time: rise (10 % to 90 %) fall (90 % to 10 %	1600 Ohm, 20 pF load 1600 Ohm, 20 pF load		0.2 0.1	1.5 1.5	μs
Operating temperature range	_	-40 [-40]	_	150 [302]	°C [°F]
Soldering temperature and time: SS552MT	infrared reflow process: po	eak temperatur	e 245 °C [473	°F] for 10 s max	ζ.

Table 2. Magnetic Characteristics (At V_{supply} = 3.8 Vdc to 30 Vdc.)

Tompovotive Donge	Operate		Release	Differential	
Temperature Range	Minimum	Maximum	Minimum	Minimum	Maximum
-20 °C to 85 °C [-4 °F to 185 °F]	_	25 Gauss	5 Gauss	_	7 Gauss
-40 °C to 150 °C [-40 °F to 302 °F]	_	25 Gauss	4 Gauss	_	8 Gauss

wave soldering process: 250 °C to 260 °C [482 °F to 500 °F] for 3 s max.

Table 3. Absolute Maximum Specifications

all other catalog listings

Characteristic	Min.	Тур.	Max.	Unit
Supply voltage	-0.5	_	30	Vdc
Voltage externally applied to output: OFF condition only OFF or ON condition	_ -0.5		30 —	Vdc
Output current	_	_	20	mA
Storage temperature	-40 [-40]	_	150 [302]	°C [°F]
Magnetic flux	_	_	no limit	Gauss

NOTICE

Absolute maximum ratings are the extreme limits the device will withstand without damage to the device. Electrical and mechanical characteristics are not guaranteed as maximum limits (above recommended operting conditions) are approached, nor will the device necessarily operate at absolute maximum ratings.



Figure 1. Block Diagram for Current Sinking Output (NPN)





Figure 2. Magnet Alignment to the Sensor IC



- Operated by magnetic fields (North or South pole) that are parallel to the sensor IC; arrows indicate direction of magnetic flux.
- Due to the inherent high sensitivity of these sensor ICs, stray magnetic fields that are parallel to the sensor IC may affect operation.

Figure 3. Mounting Dimensions (For reference only. mm/in.)






Figure 3. Mounting Dimensions (continued)



2SS52M-T2 Ammo pack tape-in-box



2SS52M-T3 Ammo pack tape-in-box




Table 4. Order Guide

Catalog Listing	Description	
2SS52M	Magnetoresistive sensor IC, omnipolar, U-pack, straight leads 14,99 mm [0.590 in] long, bulk packaging (1000 units per bag)	
SS552MT	Magnetoresistive sensor IC, omnipolar, SOT-89B surface-mount package, tape and reel packaging (1000 units per reel)	
2SS52M-S	Magnetoresistive sensor IC, omnipolar, U-pack, surface-mount package, bulk packaging (1000 units per bag)	
2SS52M-T2	Magnetoresistive sensor IC, omnipolar, U-pack, formed leads 14,99 mm [0.590 in] long, ammo pack tape-in-box packaging (5000 units per box)	
2SS52M-T3	Magnetoresistive sensor IC, omnipolar, U-pack, straight leads 14,99 mm [0.590 in] long, ammo pack tape-in-box packaging (5000 units per box)	

ADDITIONAL MATERIALS

The following associated literature is available on the Honeywell website at sensing.honeywell.com:

- Product line guide
- Product range guide
- SS552MT installation instructions
- Magnetic sensor IC selection chart
- Application Notes:
 - Magnetoresistive sensors: Position and solid state sensor
 - Blood Recovery System
- Technical Notes:
 - Solid-State Sensors Glossary of Terms
 - Interpreting Operating Characteristics for Solid-State Sensors

Find out more

Honeywell serves its customers through a worldwide network of sales offices, representatives and distributors. For application assistance, current specifications, pricing or name of the nearest Authorized Distributor, contact your local sales office.

To learn more about Honeywell's sensing and switching products, call +1-815-235-6847 or 1-800-537-6945, visit sensing.honeywell.com, or e-mail inquiries to info.sc@honeywell.com

Honeywell Sensing and Productivity Solutions

9680 Old Bailes Road Fort Mill, SC 29707 honeywell.com

△ WARNINGPERSONAL INJURY

DO NOT USE these products as safety or emergency stop devices or in any other application where failure of the product could result in personal injury.

Failure to comply with these instructions could result in death or serious injury.

△ WARNINGMISUSE OF DOCUMENTATION

- The information presented in this product sheet is for reference only. Do not use this document as a product installation guide.
- Complete installation, operation, and maintenance information is provided in the instructions supplied with each product.

Failure to comply with these instructions could result in death or serious injury.

Warranty/Remedy

Honeywell warrants goods of its manufacture as being free of defective materials and faulty workmanship. Honeywell's standard product warranty applies unless agreed to otherwise by Honeywell in writing; please refer to your order acknowledgement or consult your local sales office for specific warranty details. If warranted goods are returned to Honeywell during the period of coverage, Honeywell will repair or replace, at its option, without charge those items it finds defective. The foregoing is buyer's sole remedy and is in lieu of all other warranties, expressed or implied, including those of merchantability and fitness for a particular purpose. In no event shall Honeywell be liable for consequential, special, or indirect damages.

While we provide application assistance personally, through our literature and the Honeywell web site, it is up to the customer to determine the suitability of the product in the application.

Specifications may change without notice. The information we supply is believed to be accurate and reliable as of this printing. However, we assume no responsibility for its use.

