
PIN	NAME	FUNCTION
1	DQ	Data Input/Output Pin (Tri-State) for 3-Wire Serial Communication
2	CLK/CNV	Clock Input Pin for 3-Wire Serial Communication. Controls temperature
2	CLK/CNV	measurements when the DS1626/DS1726 is configured as a stand-alone thermostat.
3	RST	Reset Input Pin for 3-Wire Serial Communication
4	GND	Ground Pin
5	T <sub>COM</sub>	Thermostat Output Pin (Push-Pull) with Programmable Hysteresis
6	T <sub>LOW</sub>	Thermostat Output Pin (Push-Pull) with T <sub>L</sub> Trip Point
7	T <sub>HIGH</sub>	Thermostat Output Pin (Push-Pull) with T <sub>H</sub> Trip Point
8	V <sub>DD</sub>	Supply Voltage. +2.7V to +5.5V input power pin.

#### **PIN DESCRIPTION**

# Table 1. DS1626/DS1726 REGISTER SUMMARY

<b>REGISTER NAME</b> (USER ACCESS)	SIZE	MEMORY TYPE	REGISTER CONTENTS AND POWER-UP/POR STATE
Temperature (Read Only)	12 Bits	SRAM	Measured Temperature (Two's Complement) Power-Up/POR State: -60°C (1100 0100 0000)
T <sub>H</sub> (Read/Write)	12 Bits	EEPROM	Upper Alarm Trip Point (Two's Complement) Power-Up/POR State: User Defined Initial State from Factory: +15°C (0000 1111 0000)
T <sub>L</sub> (Read/Write)	12 Bits	EEPROM	Lower Alarm Trip Point (Two's Complement) Power-Up/POR State: User Defined Initial State from Factory: +10°C (0000 1010 0000)
Configuration (Various Bits are Read/Write and Read Only—See Table 3)	1 Byte	SRAM and EEPROM	Configuration and Status Information (Unsigned) 4MSbs = SRAM and 4LSbs = EEPROM Power-Up/POR State: 1000XXXX (XXXX = User Defined)

# Figure 1. DS1626/DS1726 FUNCTIONAL DIAGRAM



# **ABSOLUTE MAXIMUM RATINGS**

Voltage Range on Any Pin Relative to Ground	0.5V to +6.0V
Operating Temperature Range	55°C to +125°C
Storage Temperature Range	
Solder Dip Temperature (10s)	
Reflow Oven Temperature	

These are stress ratings only and functional operation of the device at these or any other conditions above those indicated in the operation sections of this specification is not implied. Exposure to absolute maximum rating conditions for extended periods of time may affect reliability.

#### **DC ELECTRICAL CHARACTERISTICS** $(\sqrt{-} - 2.7)(to 5.5)(T_{-} - 55^{\circ}C)(to + 125^{\circ}C)$

		5°C to +125°C.)	<b>- -</b>		<b>- -</b> ·			
PARAMETER	SYMBOL	CONDITIONS	MIN	TYP	MAX	UNITS		
Supply Voltage	$V_{DD}$	(Note 1)	2.7		5.5	V		
DS1626		$0^{\circ}$ C to $+70^{\circ}$ C,			±0.5			
Thermometer		$3.0V \le V_{DD} \le 5.5V$			±0.5			
Error	$T_{ERR}$	$0^{\circ}$ C to +70°C,			±1.25	°C		
(Note 2)		$2.7V \le V_{DD} < 3.0V$						
(1,000 =)		-55°C to +125°C			±2			
		$-10^{\circ}$ C to $+85^{\circ}$ C,			±1			
DS1726		$3.0V \le V_{DD} \le 5.5V$			<u> </u>			
Thermometer	$T_{ERR}$	$-10^{\circ}$ C to $+85^{\circ}$ C,			±1.5	°C		
Error (Note 2)		$2.7V \le V_{DD} < 3.0V$						
		-55°C to +125°C			±2			
Low-Level Input	$V_{IL}$	(Note 1)	-0.5		0.3 x V <sub>DD</sub>	V		
Voltage	· IL	(				•		
High-Level Input	$V_{IH}$	(Note 1)	0.7 x V <sub>DD</sub>		$V_{DD} + 0.3$	V		
Voltage								
Input Current each Input Pin		$0.4 < V_{I/O} < 0.9 \text{ x } V_{DD}$	-10		+10	μA		
		Temperature conversion						
	I <sub>DD</sub>	$-55^{\circ}C$ to $+85^{\circ}C$			1	- mA		
Active Supply		Temperature conversion						
Current (Note 3)		$+85^{\circ}C$ to $+125^{\circ}C$			1.25			
		$E^2$ write			400	μA		
		RST to GND				•		
Input Resistance	$R_{I}$	DQ, CLK to V <sub>DD</sub>	1			MΩ		
Standby Supply	т				1 5			
Current	I <sub>STBY</sub>	$0^{\circ}$ C to +70°C (Note 3)			1.5	μA		
THIGH, TLOW,	V <sub>OH</sub>	1mA source current	2.4					
TCOM, DQ						V		
Output Logic	V <sub>OL</sub>	4mA sink current			0.4	v		
Voltages (Note 1)								
Thermal Drift		(Note 4)		±0.2		°C		

# EEPROM AC ELECTRICAL CHARACTERISTICS

$(V_{DD} = 2.7 V \text{ to } 5.5 V, I_A = -$	55°C to +	125°C.)				
PARAMETER	SYMBOL	CONDITIONS	MIN	TYP	MAX	UNITS
EEPROM Write Cycle Time	t <sub>wr</sub>			4	10	ms
EEPROM Writes	N <sub>EEWR</sub>	$-55^{\circ}$ C to $+55^{\circ}$ C	50k			Writes
EEPROM Data Retention	t <sub>EEDR</sub>	$-55^{\circ}$ C to $+55^{\circ}$ C	10			Years

#### $27/(t_{0} = 5)/T$ 55°C to 125°C ) $\Lambda I$

# **AC ELECTRICAL CHARACTERISTICS**


#### $(V_{DD} = 2.7V \text{ to } 5.5V, T_{A} = -55^{\circ}C \text{ to } +125^{\circ}C.)$

PARAMETER	SYMBOL	CONDITIONS	MIN	TYP	MAX	UNITS
		9 bits			93.75	
Temperature Conversion Time	t	10 bits			187.5	<b>m</b> 0
Temperature Conversion Time	t <sub>TC</sub>	11 bits			375	ms
		12 bits			750	
Data In to Clock Setup	t <sub>DC</sub>	(Note 5)	35			ns
Clock to Data In Hold	t <sub>CDH</sub>	(Note 5)	40			ns
Clock to Data Out Delay	t <sub>CDD</sub>	(Notes 5, 6)			150	ns
Clock Low/High Time	t <sub>CL</sub> , t <sub>CH</sub>	(Note 5)	285			ns
Clock Frequency	f <sub>CLK</sub>	(Note 5)	0		1.75	MHz
Clock Rise/Fall Time	t <sub>R</sub> , t <sub>F</sub>	(Note 5)			500	ns
RST to Clock Setup	t <sub>RC</sub>	(Note 5)	100			ns
Clock to $\overline{RST}$ Hold	t <sub>CRH</sub>	(Note 5)	40			ns
<b>RST</b> Inactive Time	t <sub>RI</sub>	(Note 7)	125			ns
Clock High to I/O Hi-Z	t <sub>CDZ</sub>	(Note 5)			50	ns
RST Low to I/O Hi-Z	t <sub>RDZ</sub>	(Note 5)			50	ns
CNV Pulse Width	t <sub>CNV</sub>	(Note 8)	250ns		500ms	
I/O Capacitance	C <sub>I/O</sub>			10		pF
Input Capacitance	CI			5		pF


# NOTES:

- 1) All voltages are referenced to ground.
- 2) See Figure 2 for TYPICAL OPERATING CURVES.
- 3)  $I_{STBY}$ ,  $I_{DD}$  specified with DQ, CLK/ $\overline{CNV} = V_{DD}$  and  $\overline{RST} = GND$ .
- 4) Drift data is based on a 1000hr stress test at  $+125^{\circ}$ C with V<sub>DD</sub> = 5.5V.
- 5) See Timing Diagrams in Figure 3. All timing is referenced to 0.7 x  $V_{DD}$  and 0.3 x  $V_{DD}$ .
- 6) Load capacitance = 50 pF.
- 7)  $t_{RI}$  must be 10ms minimum following any write command that involves the E<sup>2</sup> memory.
- 8) 250ns is the guaranteed minimum pulse width for a conversion to start, however, a smaller pulse width may start a conversion.

# Figure 2. TYPICAL OPERATING CURVES







#### **OPERATION—MEASURING TEMPERATURE**

The DS1626/DS1726 measure temperature using a bandgap-based temperature sensor. A delta-sigma analog-to-digital converter (ADC) converts the measured temperature to a digital value that is calibrated in degrees Celsius; for Fahrenheit applications a lookup table or conversion routine must be used. Communication with the DS1626/DS1726 is achieved through a 3-wire serial interface, and all data is transmitted LSb first.

The DS1626/DS1726 can be programmed to take continuous temperature measurements (continuous conversion mode) or to take single temperature measurements on command (one-shot mode). The measurement mode is programmed by the 1SHOT bit in the configuration register as explained in the *CONFIGURATION REGISTER* section of this data sheet. The 1SHOT bit is stored in EEPROM, so it can be programmed prior to installation if desired. In continuous conversion mode, when a Start Convert T command is issued the DS1626/DS1726 perform consecutive temperature measurements until a Stop Convert T command is issued. In one-shot mode, the Start Convert T command causes one temperature measurement to be taken and then the DS1626/DS1726 return to a low-power idle state.

The resolution of the DS1626/DS1726 digital temperature data is user-configurable to 9, 10, 11, or 12 bits, corresponding to temperature increments of 0.5°C, 0.25°C, 0.125°C, and 0.0625°C, respectively. The resolution is set by the EEPROM R0 and R1 bits in the configuration register. Note that the conversion time doubles for each additional bit of resolution.

After each temperature measurement and analog-to-digital conversion, the DS1626/DS1726 store the measured temperature as a two's complement number in the 12-bit temperature register (see Figure 4). The sign bit (S) indicates if the temperature is positive or negative: for positive numbers S = 0 and for negative numbers S = 1. The Read Temperature command provides user access to the temperature register.

When the DS1626/DS1726 are configured for 12-bit resolution, all 12 bits of the temperature register will contain temperature data. For 11-bit resolution, the 11 MSbs (bits 11 through 1) of the temperature register will contain data and bit 0 will read out as 0. Likewise, for 10-bit resolution, the 10 MSbs (bits 11 through 2) will contain data, and for 9-bit the 9 MSbs (bits 11 through 3) will contain data, and all unused LSbs will contain 0s. Since the DS1626/DS1726 transmit data LSb first, when reading data from the temperature register, all 12 bits must be read in order to receive all MSbs of the measured data, regardless of the conversion resolution. Table 2 gives examples of 12-bit resolution digital output data and the corresponding temperatures.

# Figure 4. TEMPERATURE, $T_H$ , and $T_L$ REGISTER FORMAT

BIT 11	BIT 10	BIT 9	BIT 8	BIT 7	BIT 6	BIT 5	BIT 4	BIT 3	BIT 2	BIT 1	BIT 0
S	$2^{6}$	2 <sup>5</sup>	$2^{4}$	$2^{3}$	$2^{2}$	$2^{1}$	$2^{0}$	2-1	2-2	2-3	2-4
								•			

TEMPERATURE (°C)	DIGITAL OUTPUT (BINARY)	DIGITAL OUTPUT (HEX)
+125	0111 1101 0000	7D0h
+25.0625	0001 1001 0001	191h
+10.125	0000 1010 0010	0A2h
+0.5	0000 0000 1000	008h
0	0000 0000 0000	000h
-0.5	1111 1111 1000	FF8h
-10.125	1111 0101 1110	F5Eh
-25.0625	1110 0110 1111	E6Fh
-55	1100 1001 0000	C90h

### Table 2. 12-BIT RESOLUTION TEMPERATURE/DATA RELATIONSHIP

### **OPERATION—THERMOSTAT FUNCTION**

The DS1626/DS1726 thermostat outputs ( $T_{HIGH}$ ,  $T_{LOW}$ , and  $T_{COM}$ ) are updated after every temperature conversion and remain at the updated values until the next conversion completes.  $T_{HIGH}$  is asserted when the measured temperature is higher than or equal to the value stored in the  $T_H$  register, and  $T_{LOW}$  is asserted when the temperature is equal to or falls below the value in the  $T_L$  register (see Figure 5).  $T_{COM}$  uses both  $T_H$  and  $T_L$  to provide programmable hysteresis: when the measured temperature equals or exceeds  $T_H$ ,  $T_{COM}$  is asserted and it remains asserted until the temperature falls to a value equal to or below  $T_L$ . All three thermostat outputs are active-high outputs.

The Write TH and Write TL commands are used to program the 12-bit  $T_H$  and  $T_L$  registers with userdefined two's complement values. The MSb (bit 11) of each register contains the two's complement sign bit (S). For the  $T_{COM}$  thermostat output to function correctly, the  $T_L$  value must be less than the  $T_H$  value. Any unused LSbs in the  $T_H$  and  $T_L$  registers are forced to 0 regardless of the data written to those bits. The unused LSbs are determined by the conversion resolution set by R1 and R0 in the configuration register. Therefore, for 9-bit conversions bits 2 through 0 will be 0, for 10-bit conversions bit 1 and bit 0 will be 0, and for 11-bit conversions bit 0 will be 0. All bits are used for 12-bit conversions, so no bits are forced to 0. However, regardless of the conversion resolution, when writing to  $T_H$  or  $T_L$  at least 12 bits must be sent following the Write TH or Write TL commands. The reason is that data written to  $T_H$  and  $T_L$ is not saved to EEPROM until the DS1626/DS1726 have received 12 bits, so if the operation is terminated before 12 bits have been received, the data will be lost. Any additional bits sent after the first twelve are ignored (e.g., if two 8-bit words are written).

Another DS1626/DS1726 thermostat feature is the temperature-high flag (THF) and temperature-low flag (TLF) in the configuration register. These bits provide a record of whether the temperature has been greater than or equal to  $T_H$  or less than or equal to  $T_L$  at any time since the DS1626/DS1726 were powered up. If the temperature is greater than or equal to the  $T_H$  register value, the THF bit in the configuration register will be set to 1. If the temperature is less than or equal to the  $T_L$  register value, the TLF bit in the configuration register will be set to 1. Once THF and/or TLF has been set, it will remain set until the user overwrites it with a 0 or until the power is cycled.

## CPU BIT AND STAND-ALONE THERMOSTAT OPERATION


In stand-alone thermostat mode, DS1626/DS1726 thermostat functionality can be used without requiring a microcontroller to start/stop temperature conversions. The CPU bit in the configuration register determines if stand-alone mode is enabled.

When CPU = 1 stand-alone mode is disabled, and the only way to start/stop temperature conversions is by using a microcontroller to transmit Start Convert T and Stop Convert T commands, respectively.

Stand-alone mode is enabled when CPU = 0. In this mode, when  $\overline{RST} = 0$  the  $CLK/\overline{CNV}$  pin operates as a control signal to start and stop temperature measurements. Driving  $CLK/\overline{CNV}$  low initiates continuous temperature conversions that will continue until  $CLK/\overline{CNV}$  is brought high again. If the  $CLK/\overline{CNV}$  pin is driven low and then returned to a high state in less than 10ms, only one temperature conversion will be performed after which the DS1626/DS1726 will return to a low-power idle state (i.e., one-shot operation). Note that when stand-alone mode is enabled, the 1SHOT bit in the configuration register is ignored, and only the  $CLK/\overline{CNV}$  signal determines whether continuous or one-shot conversions take place.

Since  $T_H$ ,  $T_L$ , and the CPU bit are stored in EEPROM, the DS1626/DS1726 can be preprogrammed for stand-alone operation. If desired, the CLK/ $\overline{CNV}$  and  $\overline{RST}$  pin can be connected to GND so the DS1626/DS1726 will automatically begin taking temperature measurements at power-up

Normal bus communication with the DS1626/DS1726 can still take place in stand-alone mode when  $\overline{\text{RST}} = 1$ . When communication is initiated, stand-alone conversions are automatically halted. If during the bus communication continuous temperature conversions are started using the Start Convert T command, they can only be stopped by issuing a Stop Convert T command.



# Figure 5. THERMOSTAT OUTPUT OPERATION

## **CONFIGURATION REGISTER**

The configuration register allows the user to customize the DS1626/DS1726 conversion and thermostat options. It also provides information to the user about conversion status, EEPROM activity, and thermostat activity. The configuration register is arranged as shown in Figure 6 and detailed descriptions of each bit are provided in Table 3. This register can be accessed using the Read Config and Write Config commands. Note that the R1, R0, CPU, and 1SHOT bits are stored in EEPROM and all other configuration register bits are SRAM.

# **Figure 6. CONFIGURATION REGISTER**

MSb	BIT 6	BIT 5	BIT 4	BIT 3	BIT 2	BIT 1	LSb
DONE	THF	TLF	NVB	<u>R1*</u>	<u>R0*</u>	<u>CPU*</u>	1SHOT*
*NV (EEPF	ROM)						

NV (EEPROM)

### **Table 3. CONFIGURATION REGISTER BIT DESCRIPTIONS**

BIT NAME (USER ACCESS)	FUNCTIONAL DESCRIPTION
DONE (Read Only)	Power-up state = 1. DONE = 0. Temperature conversion is in progress. DONE = 1. Temperature conversion is complete.
THF (Read/Write)	Power-up state = 0. THF = 1. The measured temperature has reached or exceeded the value stored in the $T_H$ register. THF will remain a 1 until it is overwritten with a 0 by the user, the power is cycled, or a Software POR command is issued.
TLF (Read/Write)	Power-up state = 0. TLF = 1. The measured temperature has equaled or dropped below the value stored in the T <sub>L</sub> register. TLF will remain a 1 until it is overwritten with a 0 by the user, the power is cycled, or a Software POR command is issued.
NVB (Read Only)	Power-up state = 0. $NVB = 1$ . Write to an $E^2$ memory cell is in progress. NVB = 0. NV memory is not busy.
R1* (Read/Write)	Power-up state = last value written to this bit. Sets conversion resolution (see Table 4). Initial state from factory = 1.
R0* (Read/Write)	Power-up state = last value written to this bit. Sets conversion resolution (see Table 4). Initial state from factory = 1.
CPU* (Read/Write)	Power-up state = last value written to this bit. CPU = 1. Stand-alone mode is disabled. $CPU = 0$ . Stand-alone mode is enabled when $\overline{RST} = 0$ . See <i>CPU BIT AND STAND-</i> <i>ALONE THERMOSTAT OPERATION</i> section for more information. Initial state from factory = 0.
1SHOT* (Read/Write)	Power-up state = last value written to this bit. 1SHOT = 1: One-Shot Mode. The Start Convert T command initiates a single temperature conversion and then the device goes into a low-power standby state. 1SHOT = 0: Continuous Conversion Mode. The Start Convert T command initiates continuous temperature conversions. Initial state from factory = 0.

\*NV (EEPROM)

R1	R0	RESOLUTION (BITS)	CONVERSION TIME (MAX) (ms)
0	0	9	93.75
0	1	10	187.5
1	0	11	375
1	1	12	750

# **Table 4. RESOLUTION CONFIGURATION**

# **3-WIRE SERIAL DATA BUS**

The 3-wire bus consists of three signals:  $\overline{\text{RST}}$  (active-low reset), CLK (clock), and DQ (data). 3-wire communication is controlled by the  $\overline{\text{RST}}$  signal, which functions as "chip select" signal. All data is transferred LSb first over the 3-wire bus. All communication with the DS1626/DS1726 is initiated by driving  $\overline{\text{RST}}$  high. Driving  $\overline{\text{RST}}$  low terminates communications and causes DQ to go to a high-impedance state. Note that  $\overline{\text{RST}}$  must be toggled low after every communication sequence to ensure that subsequent commands are recognized by the DS1626/DS1726.

When writing to the DS1626/DS1726, data must be valid during the rising edge of CLK. During read operations the DS1626/DS1726 output data on DQ on the falling edge of CLK and the data remains valid through the following rising edge, at which time the DQ pin becomes high impedance until the next falling edge.

To communicate with the DS1626/DS1726, the master must first drive  $\overline{\text{RST}}$  high and then begin generating the CLK signal while transmitting the desired DS1626/DS1726 command byte. If the command is a Start Convert T, Stop Convert T, or Software POR command, the transaction is finished when the last bit of the command has been sent. Figure 7a illustrates a Start Convert T command sequence.

When writing to the DS1626/DS1726, the master must begin transmitting data during the clock cycle immediately following the command byte. The DS1626/DS1726 will save only the number of data bits needed for the specific transaction. For example, for the Write TH or Write TL commands, after twelve bits of data have been transmitted by the master, the DS1626/DS1726 will ignore any subsequent data transmitted before  $\overline{RST}$  goes low. Thus, if data is being transmitted in byte-length segments, the DS1626/DS1726 will load the first twelve bits into the  $T_H/T_L$  register, and the next four bits will be ignored. On the other hand, it is necessary to transmit at least the required number of bits for the requested transaction (i.e., 12-bits to  $T_H/T_L$  or 8-bits to the configuration register), because the DS1626/DS1726 will not save data until the expected number of bits have been received. Write TH and Write TL sequences are illustrated in Figure 7b and a Write Config sequence is shown in Figure 7c. Note that these figures assume byte-wide data transfers.

When reading data from the DS1626/DS1726, the DS1626/DS1726 will begin sending data during the clock cycle immediately following the command byte. After the last data byte has been sent, the DS1626/DS1726 will transmit a 0 during each subsequent clock until  $\overline{RST}$  goes low. Figure 7d illustrates a Read Temperature sequence and a Read Config transaction is shown in Figure 7e. The sequence for reading the T<sub>H</sub> or T<sub>L</sub> registers is the same as the Read Temp transaction in Figure 7d except that the Read TH or Read TL command is used.

# Figure 7. 3-WIRE COMMUNICATION

a) Start Temperature Conversion
RST
Ctart Convert T [54b] Command
Start Convert T [51h] Command b) Write to the $T_H/T_L$ Registers
$\overline{\text{RST}}$
$DQ = \frac{2}{2} (C_0 (C_1) 0 0 0 0 0 (D_0) (D_1) (D_2) (D_3) (D_4) (D_5) (D_6) (D_7) (D_8) (D_9) (D_1) $
Write TH [01h] or TL [02h] Command $T_H$ or $T_L$ Data from Master
c) Write to the Configuration Register
RST
$ \begin{array}{c} c_{LK} \\ \hline DQ \end{array} \\ \hline DQ \end{array} \\ \hline DQ \end{array} \\ \hline \begin{array}{c} DQ \end{array} \\ \hline \end{array} \\ \hline \end{array} \\ \hline \begin{array}{c} DQ \end{array} \\ \hline \end{array} \\ \hline \end{array} \\ \hline \end{array} \\ \hline \end{array} $ \\ \hline \begin{array}{c} DQ \end{array} \\ \hline \end{array} \\ \hline \end{array} \\ \hline \end{array}  \\ \hline \end{array}  \\ \hline \end{array}  \\ \hline \begin{array}{c} DQ \end{array} \\ \hline \end{array} \\ \hline \end{array} \\ \hline \end{array} \\ \hline \end{array} \\ \end{array}  \\ \hline \end{array} \\ \end{array}  \\ \hline \end{array} \\ \hline \end{array}  \\ \hline \end{array}  \\ \hline \end{array}  \\ \hline \end{array}  \\ \hline \end{array} \\ \\ \end{array}  \\ \hline \end{array} \\ \\ \end{array}  \\ \hline \end{array}  \\ \hline \end{array}  \\ \\ \end{array}  \\ \\ \end{array}  \\ \hline \end{array}  \\ \\ \\ \\ \\
Write Config [0Ch] Command Configuration Reg. Data from Master
d) Read from the Temperature Register
RST
Read Temperature [AAh] Command Temperature Data from DS1626/DS1726
e) Read from the Configuration Register
$RST \_ / $ $CLK \_ 1 1 0 1 0 1 0 0 - D_1 - D_2 - D_3 - D_4 - D_5 - D_6 - D_7 -$

Downloaded from Arrow.com.

# DS1626/DS1726 COMMAND SET

The DS1626/DS1726 command set is detailed below:

#### Start Convert T 51h 0101 0001

Initiates temperature conversions. If the DS1626/DS1726 are in one-shot mode (1SHOT = 1), only one conversion will be performed. If the devices are in continuous mode (1SHOT = 0), continuous conversions will be performed until a Stop Convert T command is issued.

#### Stop Convert T 22h 0010 0010

Stops temperature conversions when the devices are in continuous conversion mode (1SHOT = 0).

Read Temperature AAh 1010 1010

Reads the last converted temperature value from the temperature register.

<b>Read TH</b> Reads the 12-bit $T_H$ register.	A1h	1010 0001
<b>Read TL</b> Reads the 12-bit $T_L$ register.	A2h	1010 0010
Write TH* Writes the 12-bit T <sub>H</sub> register.	01h	0000 0001
Write TL* Writes the 12-bit T <sub>L</sub> register.	02h	0000 0010
Read Config Reads the 1-byte configuration	ACh on register.	1010 1100
Write Config* Writes the 1-byte configuration	<b>0Ch</b> on register.	0000 1100

#### Software POR 54h 0101 0100

Initiates a software power-on reset (POR), which stops temperature conversions and resets all registers and logic to their power-up states. The software POR allows the user to simulate cycling the power without actually powering down the device.

\*After issuing a write command, no further writes should be requested for at least 10ms due to the EEPROM write cycle time.

# PACKAGE INFORMATION

For the latest package outline information, go to <u>www.maxim-ic.com/packages</u>.

PACKAGE TYPE	PACKAGE CODE	DOCUMENT NO.
8 µSOP		<u>21-0036</u>

#### 12 of 12

Maxim/Dallas Semiconductor cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim/Dallas Semiconductor product. No circuit patent licenses are implied. Maxim/Dallas Semiconductor reserves the right to change the circuitry and specifications without notice at any time. Maxim Integrated Products, 120 San Gabriel Drive, Sunnyvale, CA 94086 408-737-7600

© 2007 Maxim Integrated Products

The Maxim logo is a registered trademark of Maxim Integrated Products, Inc. The Dallas logo is a registered trademark of Dallas Semiconductor Corporation.