COIL DATA at 23°C

High sensitive type (150mW)

ingin constant type (recinity)						
Coil Code	Coil Voltage VDC ¹⁾	Pick-up Voltage VDC ¹⁾	Drop-out Voltage VDC	Max. Voltage VDC ⁴⁾	Coil Resistance Ω	
003-H	3	2.4	0.3	7.0	60 x (1±10%)	
005-H	5	4.0	0.5	11.5	167 x (1±10%)	
006-H	6	4.8	0.6	13.8	240 x (1±10%)	
009-H	9	7.2	0.9	20.8	540 x (1±10%)	
012-H	12	9.6	1.2	27.7	960 x (1±10%)	
015-H	15	12.0	1.5	34.6	1500 x (1±10%)	
024-H	24	19.2	2.4	55.2	3840 x (1±10%)	

Notes: (1) Energizing coil with rated voltage is basic for normal operation

- Energizing coil with rated voltage is basic for normal operation of a relay. Please make sure the energized voltage to relay coil have reached the rated voltage.
 In case 5V of transistor drive circuit, it is recommended to use 4.5V type relay, and 3V to use 2.4V type relay.
 For monostable relays, if you need to drop down voltage and hold mode after reliably operating, make sure that the effective value of holding voltage is not less than 60% of the rated voltage.
 Maximum voltage refers to the maximum voltage which relay coil could endure in a short period of time.
 When user's requirements can't be found in the above table, special order allowed.

SAFETY APPROVAL RATINGS

UL/CUL	2A 30VDC				
OL/COL	1A 125VAC				
TÜV	2A 30VDC				
100	1A 125VAC				

Notes: 1) All values unspecified are at 85°C.

2) Only typical loads are listed above. Other load specifications can be available upon request.

ORDERING INFORMATION


HFD27 012 -S **Type** Coil voltage 3, 5, 6, 9, 12, 15, 24, 48VDC ¹⁾ M: Standard (280mW to 580mW) S: Sensitive (200mW) Coil power **H:** High sensitive (150mW) Special code²⁾ xxx: Customer special requirement Nil: Standard

Notes: 1) 48VDC coil voltage is only for standard version.

- 2) The customer special requirement express as special code after evaluating by Hongfa.
- 3) Standard tube packing length is 527mm. Any special requirement needed, please contact us for more details.
- 4) For products that should meet the explosion-proof requirements of "IEC 60079 series", please note [Ex] after the specification while placing orders.Not all products have explosion-proof certification,so please contact us if necessary, in order to select the suitable products.

OUTLINE DIMENSIONS, WIRING DIAGRAM AND PC BOARD LAYOUT

Unit: mm




Remark: 1) In case of no tolerance shown in outline dimension: outline dimension ≤1mm, tolerance should be ±0.2mm; outline dimension >1mm and ≤5mm, tolerance should be ±0.3mm; outline dimension >5mm, tolerance should be ±0.4mm.


- 2) The tolerance without indicating for PCB layout is always ±0.1mm.
 3) The width of the gridding is 2.54mm.

CHARACTERISTIC CURVES

MAXIMUM SWITCHING POWER



ENDURANCE CURVE



Test conditions:Resistive load, at 85°C, 1s on 9s off.

Notice

- 1) To avoid using relays under strong magnetic field which will change the parameters of relays such as pick-up voltage and drop-out voltage.
- 2) Energizing coil with rated voltage is basic for normal operation of a relay, please make sure the energized voltage to relay coil have reached the rated voltage. Regarding latching relay, in order to maintain the "set" or "reset" status, impulse width of the rated voltage applied to coil should be more than 5 times of "set" or "reset" time.
- 3) For a monosteady state relay, after the relay is reliably operated, if it needs to be kept under pressure, make sure that the effective value of the voltage is not less than 60 % of the rated voltage;
- 4) The relay may be damaged because of falling or when shocking conditions exceed the requirement.
- 5) Please use wave soldering or manual soldering for straight-in relay. If you need reflow welding, please confirm the feasibility with us.
- 6)Contact is recommended for suitable condition and specifications if water cleaning or surface process is involved in assembling relays on PCB.
- 7)Regarding the plastic sealed relay, we should leave it cooling naturally untill below 40°C after welding, then clean it and deal with coating, remarkably the temperature of solvents should also be controlled below 40°C. Please avoid cleaning the relay by ultrasonic, avoid using the solvents like gasoline, Freon, and so on, which would affect the configuration of relay or influence the environment.
- 8) When applied with continuous current, the heat from relay coil will age its isolation. Thus, please do not ground connected the coil to reduce electrical errosion if possible. And please provide protection circuit to avoid broken wire and losses.
- 9)Please make sure that there are no silicon-based substances (such as silicon rubber, silicone oil, silicon-based coating agents, silicon fillers, etc.) around the relay, because it will generate silicon-containing volatile gas, which may cause poor contact in case of silicon-containing volatile gas sticking on contact
- 10) About preferable condition of operation, storage and transportation, please refer to "Explanation to terminology and guidetines of relay".

Disclaimer

The specification is for reference only. See to "Terminology and Guidelines" for more information. Specifications subject to change without notice. We could not evaluate all the performance and all the parameters for every possible application. Thus the user should be in a right position to choose the suitable product for their own application. If there is any query, please contact Hongfa for the technical service. However, it is the user's responsibility to determine which product should be used only.

© Xiamen Hongfa Electroacoustic Co., Ltd. All rights of Hongfa are reserved.