## Distinctive Characteristics

Low profile body of MRF model accommodates space limitations required for PCB mounting. For the MRA and MRK bushing mount models, the range of behind panel body depths is .323" to .669" (8.2mm to 17.0mm).

Positive detent mechanism for distinct feel and audible feedback.

Metal bushing and housing construction increases durability.

Adjustable stopper plate allows 2–12 position settings.


High contact reliability achieved by the self-cleaning contact mechanism.

Break-before-make contact timing with sliding contacts in MRA and rotary contactor disk in MRF and MRK models.

Interior housing seal and molded-in PC terminals, plus shaft rubber o-ring on MRA and MRK and polyamide cover on MRF model, allow cleaning after automated soldering.

MRK model meets IP67 of IEC60529 specifications (similar to NEMA 4 & 13).

Actual Size





F

G

Н

Green

Blue

Gray

MR

Α

F

K

**Actuators & Terminals** 

Low Profile Shaft Actuated with

with PC Terminals

PC Terminals

#### TYPICAL SWITCH ORDERING EXAMPLE **Poles & Circuits** Knobs Colors Shaft Actuated with PC Terminals 112 SP with 2-12 Positions Plain Black For Plain Knob Α Small Color Tipped Low Profile Screwdriver Actuated DP with 2-6 Positions В 206 No Black Code 403 4P with 2-3 Positions C Large Color Tipped For Color Tipped Black Α В White C Red **DESCRIPTION FOR TYPICAL ORDERING EXAMPLE** E Yellow

### Plain Black Knob DP with 2-6 Adjustable Positions

Shaft Actuated with

PC Terminals


**MRA206-A** 

#### **ACTUATORS & TERMINALS**



**Shaft Actuated** with PC Terminals






Shaft **Terminal** 




**Low Profile Screwdriver Actuated** with PC Terminals





Slotted for Screwdriver




Terminal



**Low Profile Shaft Actuated** with PC Terminals








Shaft



Terminal




#### POSITION SETTING FOR MRA, MRF, & MRK MODELS

Each switch is supplied with the stopper set for the maximum number of positions allowed for that model. Prior to installation, the desired position setting should be made. Contact factory for continuous rotation.

#### **MRF Models**

- 1. Remove the protective cover from the switch body.
- 2. Turn the shaft counterclockwise to the extreme left by using a screwdriver.
- Inside the cover is a magnifying lens which would be positioned over the number which is to be the maximum position used; when the cover is then snapped into the switch, the projection beside the lens fits into the correct hole for setting the stop.



#### MRK & MRA Models

- Using the actuator knob, turn the shaft counterclockwise to the extreme left. If the shaft is not turned counterclockwise to the extreme left, proper setting cannot be achieved. At this extreme position, the white line on the knob points to the number 1 position shown on the side of the switch.
- Remove the knob from the shaft and loosen the nut far enough to allow raising the stopper plate, plus washer(s), for resetting to the desired position.
- 3. Note the position numbers on the side of the switch; these correspond to the terminal numbers and stopper holes. Insert the stopper in the hole numbered for the maximum desired number of stop settings. Satisfactory switch functioning cannot be assured if the stopper plate is not properly positioned.
- 4. Tighten the nut (beveled side up) firmly against the stopper plate.

## Standard Mounting Hardware Packaged Loose with Each Switch:

|            | ———— Hex Face Nut  |                   |
|------------|--------------------|-------------------|
|            | Locking Ring       |                   |
|            | Lockwasher —       |                   |
|            | Rubber Ring (MRK)  |                   |
|            | Factory Assembled: |                   |
|            | Hex Nut            |                   |
|            | Stopper Plate      |                   |
|            | Metal Washer (MRA) |                   |
|            | Rubber Washer      |                   |
| A          |                    | Ä                 |
|            |                    |                   |
| M R - K112 |                    |                   |
|            |                    | MR-A <sup>1</sup> |
|            |                    |                   |
|            |                    |                   |




Touch

苣

# Supplement | Acc


#### TYPICAL SWITCH DIMENSIONS




**MRA112** 


**MRF** • PC Terminals








1 Pole



2 Pole





4 Pole


MRF403

MRK • PC Terminals 1 Pole










2 Pole




4 Pole

MRK112

MRK devices are designed to be panel mounted. Installation without panel mounting will affect reliability.

## FOOTPRINTS



## Rockers


#### AT433 Plain Black

Material: **Polyacetal** (19.0) Dia .748 Color: (11.0) Dia -Black only (13.0) .512 (0.5)

#### AT4103 Small **Color Tipped**

Base Material: Polyester Base Color: Black

Polyamide Tip Colors: A, B, C, E, F, G, H




**KNOBS** 

AT4104 Large Color Tipped

Base Material: **Polyester** Base Color: Black

Polyamide Tip Colors: A, B, C, E, F, G, H



**Color Codes:** 



Black













Gray

#### PANEL CUTOUTS & MAXIMUM EFFECTIVE PANEL THICKNESS

#### MRA & MRK

#### **Nonsealed Panel**

Without Keyway (2.2) Dia -



#### **MRK** Sealed Panel



With Standard Hardware on Nonsealed Panel: MRA .067" (1.7mm) MRK .087" (2.2mm)

Without Locking Ring on Nonsealed Panel: MRA .098" (2.5mm) MRK .118" (3.0mm)

With AT513M & AT535 only on Sealed Panel: MRK .106" (2.7mm)

#### STANDARD MOUNTING HARDWARE


#### AT513M Metric Hexagon Nut

Material: Brass, nickel plating 1 for MRA; 1 for MRK

-M6 P0.75


#### AT545 **Locking Ring** Material:

Steel, chromate over zinc plating 1 for MRA; 1 for MRK




#### AT509 Lockwasher

Material: Steel, chromate over zinc plating 1 for MRA; 1 for MRK



#### AT535 **Rubber Ring**


Material: Nitrile butadiene rubber 1 for MRK





### **OPTIONAL SUPPORT BRACKET**

## Support Bracket for MRK

Material: Steel with tin plating







A support bracket is needed when the MRK is mounted only to a PC board and does not have the bushing through a panel.

